



ETEKCITY EL11 Digital Luggage Scale User Manual

[Home](#) » [ETEKCITY](#) » ETEKCITY EL11 Digital Luggage Scale User Manual

*ETEKCITY EL11 Digital Luggage Scale
User Manual*



DIGITAL LUGGAGE SCALE

Model No.: EL11

Questions or Concerns?
(855) 6863835 • support@etekcity.com

support@etekcity.com

Thank you.

Thank you for purchasing the Etekcity Digital Luggage Scale. This product is designed to accurately weigh many types of luggage. Please read the information in this user manual to use this product safely and gain the most benefit from its many features.

Contents [[hide](#)]

- 1 Specifications
- 2 Cleaning & Maintenance
- 3 Function Diagram
 - 3.1 Button Functions
- 4 Installing & Replacing the Battery
- 5 Weighing
- 6 Reading Temperature
- 7 Warranty Information
- 8 Customer Support
- 9 Documents / Resources
- 10 Related Posts


Specifications

- Room temperature display
- Easy-to-read LCD display (0.44" digits)
- Capacity: 110 lb (50 kg)
- Graduation: 0.1 lb (50 g)
- Battery: 1 x 3V CR2032 (lithium)
- Low battery and overload indication

Cleaning & Maintenance


- Use a slightly damp cloth to clean the scale. Do not immerse the scale in water or use chemical cleaning agents.
- Ensure that there is no stress on the triangle ring when not in use.

Function Diagram



Button Functions




-  Turns the scale on or off (hold for 2 seconds to turn off)
- UNIT : Switch between the weight and temperature measurement units

Installing & Replacing the Battery

- Hold the scale in one hand, and slide out the battery holder with the other hand.
- Push corner A on the battery holder outward to release the battery.
- Insert the new battery under notches B and C. Press the other side of the battery until it clips into corner A.
- Insert the battery holder back into the scale.

Note:

- Battery: 1 x 3V CR2032 (lithium)
- The LCD will display “Lo” when the battery power is low. When this occurs, you should replace the battery as soon as possible.



Battery Holder

Weighing

1. Press the POWER button to turn on the scale.
2. Press UNIT to select the weight unit, if needed. If the scale does not display 0, ensure there is no stress on the triangle ring and press the Z/T button.
3. Strap the belt on the scale through the luggage handle and secure the hook of the belt on the triangle ring.
4. Lift the scale gently, making sure it is horizontal and balanced. Wait until the weight reading stabilizes, flashes 3 times, and locks. The scale will display the reading for 2 minutes, then shut off if no button is pressed.

5. To weigh again, remove the luggage or let the belt go slack and press Z/T to reset the display to 0.

Reading Temperature

1. Press the POWER button to turn on the scale. When the LCD displays 0, press UNIT to switch to temperature mode.
2. The LCD will display “—” and then display the current ambient temperature.

Warranty Information



<https://www.etekcity.com/warranty>

Scan Here to Receive Exclusive News

Your product comes with 2 years of warranty, starting from the date of purchase.

1. Scan the QR code or visit [etekcity.com/warranty](https://www.etekcity.com/warranty).
2. Enter your purchase info to receive exclusive news.
3. Learn about our quality customer support and gain easy access to warranty information.

Customer Support

Etekcity Corporation

1202 N. Miller St., Suite A Anaheim, CA 92806

Email: support@etekcity.com


Toll-Free: (855) 686-3835

Support Hours

Monday Friday 9:00 am 5:00 pm PST/PDT

*Please have your order number ready before contacting Customer Support.

Documents / Resources

	<p>ETEKCITY EL11 Digital Luggage Scale [pdf] User Manual EL11, Digital Luggage Scale</p>
---	--

